

WATERLINE FLUSHING AFTER CONSTRUCTION/SYSTEM DISINFECTION WITH DISCHARGE TO STORM DRAIN

1. Preparation

- a. Determine chlorine content of discharged water, and select de-chlorination equipment to be used.
- b. Determine flow path of discharge.

2. Process

- a. Protect inlets in flow path.
- b. Install de-chlorination equipment.
- c. Sweep and clean flow path.
- d. Use diffuser to reduce velocities.

3. Clean-up

- a. Pick up inlet protection.
- b. Clean flow paths.
- c. Remove equipment from flush point.

4. Documentation

- a. Residual test of discharged water.